# WORK INSTRUCTION

**Document ID:** DOC-0001993
**Project:** PRJ-017
**Uploaded on:** 2025-06-10
**Uploaded by:** user096
**Export class:** EAR99

## Assembly of P-102688 at plant PLT02

**Part Number:** P-102688
**Revision:** B.1
**Plant:** PLT02
**Station:** ST-63
**Torque (Nm):** 2.5
**Cycle time (s):** 249

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Record result

Step 6: Clean mating surface

Step 7: Move to next station