WORK INSTRUCTION

Document ID: DOC-0002005
Project: PRJ-016
Uploaded on: 2025-06-16
Uploaded by: user003
Export class: EAR99

Assembly of P-103171 at plant PLT02

Part Number: P-103171
Revision: A.1
Plant: PLT02
Station: ST-38
Torque (Nm): 8
Cycle time (s): 93

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Clean mating surface

Assembly of P-100050 at plant PLT03

Part Number: P-100050
Revision: C.1
Plant: PLT03
Station: ST-93
Torque (Nm): 8
Cycle time (s): 121

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Visual check

Step 4: Move to next station

Step 5: Fit fasteners

Assembly of P-103100 at plant PLT02

Part Number: P-103100
Revision: A.1
Plant: PLT02
Station: ST-65
Torque (Nm): 5
Cycle time (s): 276

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Record result

Step 5: Apply thread locker

Step 6: Move to next station