WORK INSTRUCTION

Document ID: DOC-0002047
Project: PRJ-018
Uploaded on: 2025-07-02
Uploaded by: user053
Export class: EAR99

Assembly of P-101196 at plant PLT04

Part Number: P-101196
Revision: A.1
Plant: PLT04
Station: ST-32
Torque (Nm): 8
Cycle time (s): 233

Step 1: Record result

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Record result

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Apply thread locker

Assembly of P-101499 at plant PLT03

Part Number: P-101499
Revision: A.1
Plant: PLT03
Station: ST-65
Torque (Nm): 5
Cycle time (s): 49

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Apply thread locker