EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002074
Project: PRJ-036
Uploaded on: 2025-07-14
Uploaded by: user131
Export class: ECCN-3A001

Assembly of P-101462 at plant PLT04

Part Number: P-101462
Revision: B.1
Plant: PLT04
Station: ST-94
Torque (Nm): 12
Cycle time (s): 114

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Clean mating surface

Step 8: Fit fasteners

Assembly of P-102710 at plant PLT03

Part Number: P-102710
Revision: A.1
Plant: PLT03
Station: ST-98
Torque (Nm): 12
Cycle time (s): 166

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Record result