WORK INSTRUCTION

Document ID: DOC-0002081
Project: PRJ-006
Uploaded on: 2025-07-17
Uploaded by: user033
Export class: EAR99

Assembly of P-103184 at plant PLT03

Part Number: P-103184
Revision: A.1
Plant: PLT03
Station: ST-89
Torque (Nm): 20
Cycle time (s): 166

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Record result

Step 4: Visual check

Step 5: Clean mating surface

Assembly of P-100943 at plant PLT04

Part Number: P-100943
Revision: A.1
Plant: PLT04
Station: ST-72
Torque (Nm): 20
Cycle time (s): 139

Step 1: Record result

Step 2: Clean mating surface

Step 3: Record result

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Torque to specification