WORK INSTRUCTION

Document ID: DOC-0002088
Project: PRJ-004
Uploaded on: 2025-07-20
Uploaded by: user151
Export class: EAR99

Assembly of P-102705 at plant PLT01

Part Number: P-102705
Revision: A.1
Plant: PLT01
Station: ST-57
Torque (Nm): 20
Cycle time (s): 122

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Apply thread locker

Assembly of P-102351 at plant PLT01

Part Number: P-102351
Revision: A.1
Plant: PLT01
Station: ST-23
Torque (Nm): 5
Cycle time (s): 116

Step 1: Record result

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Move to next station

Assembly of P-101203 at plant PLT03

Part Number: P-101203
Revision: A.1
Plant: PLT03
Station: ST-58
Torque (Nm): 8

Cycle time (s): 269

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Move to next station