WORK INSTRUCTION

Document ID: DOC-0002095
Project: PRJ-034
Uploaded on: 2025-07-22
Uploaded by: user197
Export class: EAR99

Assembly of P-102246 at plant PLT03

Part Number: P-102246
Revision: B.1
Plant: PLT03
Station: ST-22
Torque (Nm): 2.5
Cycle time (s): 212

Step 1: Visual check

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Move to next station

Assembly of P-100588 at plant PLT02

Part Number: P-100588
Revision: A.1
Plant: PLT02
Station: ST-35
Torque (Nm): 5
Cycle time (s): 115

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Record result

Step 4: Record result

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Clean mating surface

Step 8: Apply thread locker

Assembly of P-100468 at plant PLT02

Part Number: P-100468
Revision: A.1
Plant: PLT02
Station: ST-61
Torque (Nm): 5

Cycle time (s): 80

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Apply thread locker