WORK INSTRUCTION

Document ID: DOC-0002124
Project: PRJ-010
Uploaded on: 2025-08-04
Uploaded by: user016
Export class: EAR99

Assembly of P-100139 at plant PLT02

Part Number: P-100139
Revision: C.1
Plant: PLT02
Station: ST-92
Torque (Nm): 8
Cycle time (s): 289

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Visual check

Assembly of P-101431 at plant PLT01

Part Number: P-101431
Revision: A.1
Plant: PLT01
Station: ST-39
Torque (Nm): 5
Cycle time (s): 284

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Record result

Assembly of P-100741 at plant PLT01

Part Number: P-100741
Revision: B.1
Plant: PLT01
Station: ST-91
Torque (Nm): 8
Cycle time (s): 202

Step 1: Move to next station

Step 2: Record result

Step 3: Record result

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Step 8: Apply thread locker