**EXPORT CONTROLLED - ECCN 3A001**

# WORK INSTRUCTION

**Document ID:** DOC-0002140
**Project:** PRJ-023
**Uploaded on:** 2025-08-16
**Uploaded by:** user073
**Export class:** ECCN-3A001

## Assembly of P-101133 at plant PLT03

**Part Number:** P-101133
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-92
**Torque (Nm):** 5
**Cycle time (s):** 54

Step 1: Record result

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Fit fasteners

Step 8: Visual check

## Assembly of P-102913 at plant PLT03

**Part Number:** P-102913
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-95
**Torque (Nm):** 2.5
**Cycle time (s):** 244

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Record result

Step 4: Record result

Step 5: Clean mating surface

Step 6: Apply thread locker

## Assembly of P-102670 at plant PLT04

**Part Number:** P-102670
**Revision:** A.1
**Plant:** PLT04

| | |
|---|---|
| **Station:** | ST-92 |
| **Torque (Nm):** | 20 |
| **Cycle time (s):** | 121 |

Step 1: Visual check

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Torque to specification

Step 7: Record result

Step 8: Visual check