WORK INSTRUCTION

Document ID: DOC-0002182
Project: PRJ-004
Uploaded on: 2025-09-12
Uploaded by: user142
Export class: EAR99

Assembly of P-101009 at plant PLT01

Part Number: P-101009
Revision: C.1
Plant: PLT01
Station: ST-98
Torque (Nm): 12
Cycle time (s): 265

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Clean mating surface

Step 7: Apply thread locker

Assembly of P-101541 at plant PLT03

Part Number: P-101541
Revision: A.1
Plant: PLT03
Station: ST-36
Torque (Nm): 8
Cycle time (s): 75

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Record result

Step 4: Clean mating surface

Step 5: Inspect incoming part