WORK INSTRUCTION

Document ID: DOC-0002186
Project: PRJ-015
Uploaded on: 2025-09-14
Uploaded by: user078
Export class: EAR99

Assembly of P-101612 at plant PLT02

Part Number: P-101612
Revision: A.1
Plant: PLT02
Station: ST-32
Torque (Nm): 20
Cycle time (s): 233

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Record result

Step 7: Visual check

Step 8: Fit fasteners

Assembly of P-102135 at plant PLT04

Part Number: P-102135
Revision: B.1
Plant: PLT04
Station: ST-93
Torque (Nm): 20
Cycle time (s): 105

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Fit fasteners