WORK INSTRUCTION

Document ID: DOC-0002190
Project: PRJ-029
Uploaded on: 2025-09-15
Uploaded by: user106
Export class: EAR99

Assembly of P-101116 at plant PLT03

Part Number: P-101116
Revision: A.1
Plant: PLT03
Station: ST-97
Torque (Nm): 5
Cycle time (s): 88

Step 1: Move to next station

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Record result

Step 5: Torque to specification

Step 6: Inspect incoming part

Assembly of P-102091 at plant PLT01

Part Number: P-102091
Revision: A.1
Plant: PLT01
Station: ST-20
Torque (Nm): 5
Cycle time (s): 173

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Torque to specification