WORK INSTRUCTION

Document ID: DOC-0002192
Project: PRJ-012
Uploaded on: 2025-09-16
Uploaded by: user114
Export class: EAR99

Assembly of P-103041 at plant PLT04

Part Number: P-103041
Revision: A.1
Plant: PLT04
Station: ST-34
Torque (Nm): 8
Cycle time (s): 71

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-102421 at plant PLT03

Part Number: P-102421
Revision: A.1
Plant: PLT03
Station: ST-69
Torque (Nm): 5
Cycle time (s): 185

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Visual check

Step 4: Record result

Step 5: Record result

Assembly of P-102467 at plant PLT02

Part Number: P-102467
Revision: A.1
Plant: PLT02
Station: ST-78
Torque (Nm): 12
Cycle time (s): 181

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Fit fasteners