WORK INSTRUCTION

Document ID: DOC-0002201
Project: PRJ-040
Uploaded on: 2025-09-18
Uploaded by: user007
Export class: EAR99

Assembly of P-100420 at plant PLT01

Part Number: P-100420
Revision: A.1
Plant: PLT01
Station: ST-68
Torque (Nm): 20
Cycle time (s): 126

Step 1: Torque to specification

Step 2: Visual check

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Assembly of P-100754 at plant PLT04

Part Number: P-100754
Revision: A.1
Plant: PLT04
Station: ST-71
Torque (Nm): 5
Cycle time (s): 95

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Visual check

Step 7: Record result

Assembly of P-103411 at plant PLT02

Part Number: P-103411
Revision: A.1
Plant: PLT02
Station: ST-11
Torque (Nm): 8

Cycle time (s): 92

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Record result

Step 5: Clean mating surface

Step 6: Torque to specification