WORK INSTRUCTION

Document ID: DOC-0002250
Project: PRJ-002
Uploaded on: 2025-10-08
Uploaded by: user113
Export class: EAR99

Assembly of P-100454 at plant PLT03

Part Number: P-100454
Revision: A.1
Plant: PLT03
Station: ST-59
Torque (Nm): 8
Cycle time (s): 91

Step 1: Clean mating surface

Step 2: Record result

Step 3: Visual check

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Fit fasteners

Assembly of P-102132 at plant PLT04

Part Number: P-102132
Revision: A.1
Plant: PLT04
Station: ST-64
Torque (Nm): 20
Cycle time (s): 152

Step 1: Visual check

Step 2: Record result

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Apply thread locker

Assembly of P-100059 at plant PLT01

Part Number: P-100059
Revision: A.1
Plant: PLT01
Station: ST-47
Torque (Nm): 2.5
Cycle time (s): 41

Step 1: Visual check

Step 2: Record result

Step 3: Move to next station

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Fit fasteners