WORK INSTRUCTION

Document ID: DOC-0002251
Project: PRJ-007
Uploaded on: 2025-10-08
Uploaded by: user034
Export class: EAR99

Assembly of P-102876 at plant PLT04

Part Number: P-102876
Revision: A.1
Plant: PLT04
Station: ST-62
Torque (Nm): 8
Cycle time (s): 248

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Move to next station

Step 8: Record result

Assembly of P-100020 at plant PLT03

Part Number: P-100020
Revision: A.1
Plant: PLT03
Station: ST-32
Torque (Nm): 12
Cycle time (s): 146

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Apply thread locker

Assembly of P-102670 at plant PLT04

Part Number: P-102670
Revision: A.1
Plant: PLT04
Station: ST-40
Torque (Nm): 20

Cycle time (s): 39

Step 1: Record result

Step 2: Record result

Step 3: Record result

Step 4: Record result

Step 5: Fit fasteners

Step 6: Fit fasteners