WORK INSTRUCTION

Document ID: DOC-0002305
Project: PRJ-033
Uploaded on: 2025-11-07
Uploaded by: user168
Export class: EAR99

Assembly of P-102630 at plant PLT04

Part Number: P-102630
Revision: A.1
Plant: PLT04
Station: ST-35
Torque (Nm): 20
Cycle time (s): 60

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Record result

Step 5: Move to next station

Step 6: Clean mating surface

Assembly of P-100352 at plant PLT03

Part Number: P-100352
Revision: B.1
Plant: PLT03
Station: ST-20
Torque (Nm): 2.5
Cycle time (s): 166

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Apply thread locker

Assembly of P-101372 at plant PLT03

Part Number: P-101372
Revision: A.1
Plant: PLT03
Station: ST-74
Torque (Nm): 8
Cycle time (s): 67

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Visual check