# WORK INSTRUCTION

**Document ID:** DOC-0002330
**Project:** PRJ-016
**Uploaded on:** 2025-11-18
**Uploaded by:** user126
**Export class:** EAR99

## Assembly of P-103616 at plant PLT02

**Part Number:** P-103616
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-93
**Torque (Nm):** 12
**Cycle time (s):** 227

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Record result

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Record result

Step 7: Move to next station

Step 8: Apply thread locker

## Assembly of P-103646 at plant PLT03

**Part Number:** P-103646
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-92
**Torque (Nm):** 8
**Cycle time (s):** 148

Step 1: Apply thread locker

Step 2: Record result

Step 3: Torque to specification

Step 4: Record result

Step 5: Move to next station

Step 6: Visual check

Step 7: Inspect incoming part

## Assembly of P-101653 at plant PLT04

**Part Number:** P-101653
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-19

| | |
|---|---|
| **Torque (Nm):** | 8 |
| **Cycle time (s):** | 137 |

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Record result