WORK INSTRUCTION

Document ID: DOC-0002399
Project: PRJ-026
Uploaded on: 2025-12-22
Uploaded by: user159
Export class: EAR99

Assembly of P-101953 at plant PLT02

Part Number: P-101953
Revision: A.1
Plant: PLT02
Station: ST-25
Torque (Nm): 5
Cycle time (s): 46

Step 1: Fit fasteners

Step 2: Record result

Step 3: Move to next station

Step 4: Visual check

Step 5: Move to next station

Step 6: Clean mating surface

Assembly of P-101543 at plant PLT02

Part Number: P-101543
Revision: A.1
Plant: PLT02
Station: ST-32
Torque (Nm): 12
Cycle time (s): 182

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Fit fasteners

Step 7: Fit fasteners

Step 8: Torque to specification

Assembly of P-100197 at plant PLT02

Part Number: P-100197
Revision: A.1
Plant: PLT02
Station: ST-66
Torque (Nm): 5

Cycle time (s): 109

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Torque to specification