WORK INSTRUCTION

Document ID: DOC-0002426
Project: PRJ-030
Uploaded on: 2026-01-02
Uploaded by: user187
Export class: EAR99

Assembly of P-103871 at plant PLT01

Part Number: P-103871
Revision: A.1
Plant: PLT01
Station: ST-28
Torque (Nm): 5
Cycle time (s): 220

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Visual check

Step 5: Torque to specification

Assembly of P-102048 at plant PLT02

Part Number: P-102048
Revision: A.1
Plant: PLT02
Station: ST-78
Torque (Nm): 2.5
Cycle time (s): 42

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Record result

Step 6: Visual check

Step 7: Record result

Step 8: Record result

Assembly of P-100128 at plant PLT01

Part Number: P-100128
Revision: B.1
Plant: PLT01
Station: ST-92
Torque (Nm): 12
Cycle time (s): 147

Step 1: Move to next station

Step 2: Visual check

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Visual check