WORK INSTRUCTION

Document ID: DOC-0002434
Project: PRJ-016
Uploaded on: 2026-01-05
Uploaded by: user188
Export class: EAR99

Assembly of P-103862 at plant PLT01

Part Number: P-103862
Revision: A.1
Plant: PLT01
Station: ST-32
Torque (Nm): 2.5
Cycle time (s): 167

Step 1: Visual check

Step 2: Visual check

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Inspect incoming part

Assembly of P-100067 at plant PLT02

Part Number: P-100067
Revision: C.1
Plant: PLT02
Station: ST-85
Torque (Nm): 2.5
Cycle time (s): 289

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Inspect incoming part

Step 8: Record result