WORK INSTRUCTION

Document ID: DOC-0002458
Project: PRJ-012
Uploaded on: 2026-01-17
Uploaded by: user185
Export class: EAR99

Assembly of P-100176 at plant PLT03

Part Number: P-100176
Revision: C.1
Plant: PLT03
Station: ST-30
Torque (Nm): 2.5
Cycle time (s): 71

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Inspect incoming part

Assembly of P-100859 at plant PLT02

Part Number: P-100859
Revision: C.1
Plant: PLT02
Station: ST-45
Torque (Nm): 20
Cycle time (s): 160

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Record result

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Fit fasteners

Assembly of P-100136 at plant PLT02

Part Number: P-100136
Revision: C.1
Plant: PLT02
Station: ST-21
Torque (Nm): 5
Cycle time (s): 267

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Record result