# WORK INSTRUCTION

**Document ID:** DOC-0002489
**Project:** PRJ-010
**Uploaded on:** 2026-01-31
**Uploaded by:** user017
**Export class:** EAR99

## Assembly of P-101437 at plant PLT01

**Part Number:** P-101437
**Revision:** B.1
**Plant:** PLT01
**Station:** ST-73
**Torque (Nm):** 12
**Cycle time (s):** 299

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Apply thread locker

## Assembly of P-102372 at plant PLT03

**Part Number:** P-102372
**Revision:** B.1
**Plant:** PLT03
**Station:** ST-69
**Torque (Nm):** 2.5
**Cycle time (s):** 86

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Inspect incoming part