WORK INSTRUCTION

Document ID: DOC-0002505
Project: PRJ-022
Uploaded on: 2026-02-07
Uploaded by: user007
Export class: EAR99

Assembly of P-104012 at plant PLT01

Part Number: P-104012
Revision: A.1
Plant: PLT01
Station: ST-59
Torque (Nm): 20
Cycle time (s): 261

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Torque to specification

Step 7: Inspect incoming part

Step 8: Clean mating surface

Assembly of P-101978 at plant PLT03

Part Number: P-101978
Revision: A.1
Plant: PLT03
Station: ST-45
Torque (Nm): 12
Cycle time (s): 277

Step 1: Clean mating surface

Step 2: Record result

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Fit fasteners