WORK INSTRUCTION

Document ID: DOC-0002530
Project: PRJ-032
Uploaded on: 2026-02-16
Uploaded by: user101
Export class: EAR99

Assembly of P-103737 at plant PLT01

Part Number: P-103737
Revision: A.1
Plant: PLT01
Station: ST-82
Torque (Nm): 2.5
Cycle time (s): 245

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Move to next station

Assembly of P-103617 at plant PLT01

Part Number: P-103617
Revision: A.1
Plant: PLT01
Station: ST-89
Torque (Nm): 8
Cycle time (s): 270

Step 1: Visual check

Step 2: Record result

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Move to next station

Step 6: Record result