**ITAR CONTROLLED - USML CATEGORY XIX**

# WORK INSTRUCTION

**Document ID:** DOC-0002546
**Project:** PRJ-033
**Uploaded on:** 2026-02-24
**Uploaded by:** user074
**Export class:** ITAR-USML-XIX

## Assembly of P-101772 at plant PLT04

**Part Number:** P-101772
**Revision:** B.1
**Plant:** PLT04
**Station:** ST-76
**Torque (Nm):** 5
**Cycle time (s):** 74

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Move to next station

Step 6: Move to next station

## Assembly of P-102076 at plant PLT04

**Part Number:** P-102076
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-57
**Torque (Nm):** 5
**Cycle time (s):** 104

Step 1: Apply thread locker

Step 2: Record result

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Record result

Step 6: Fit fasteners

Step 7: Apply thread locker

Step 8: Torque to specification