WORK INSTRUCTION

Document ID: DOC-0002561
Project: PRJ-020
Uploaded on: 2026-03-04
Uploaded by: user049
Export class: EAR99

Assembly of P-101369 at plant PLT04

Part Number: P-101369
Revision: A.1
Plant: PLT04
Station: ST-45
Torque (Nm): 20
Cycle time (s): 69

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Visual check

Step 7: Move to next station

Step 8: Apply thread locker

Assembly of P-100855 at plant PLT03

Part Number: P-100855
Revision: A.1
Plant: PLT03
Station: ST-39
Torque (Nm): 20
Cycle time (s): 241

Step 1: Record result

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Torque to specification

Step 8: Move to next station

Assembly of P-101380 at plant PLT02

Part Number: P-101380
Revision: A.1
Plant: PLT02

Station:	ST-51
Torque (Nm):	8
Cycle time (s):	31

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Torque to specification