WORK INSTRUCTION

Document ID: DOC-0002628
Project: PRJ-016
Uploaded on: 2026-04-05
Uploaded by: user114
Export class: EAR99

Assembly of P-103542 at plant PLT02

Part Number: P-103542
Revision: A.1
Plant: PLT02
Station: ST-98
Torque (Nm): 20
Cycle time (s): 145

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Torque to specification

Step 7: Clean mating surface

Step 8: Torque to specification

Assembly of P-100864 at plant PLT01

Part Number: P-100864
Revision: B.1
Plant: PLT01
Station: ST-66
Torque (Nm): 8
Cycle time (s): 208

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Record result

Step 7: Move to next station

Assembly of P-102237 at plant PLT02

Part Number: P-102237
Revision: A.1
Plant: PLT02
Station: ST-57

Torque (Nm):	2.5
Cycle time (s):	169

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Record result

Step 6: Move to next station

Step 7: Visual check

Step 8: Record result