WORK INSTRUCTION

Document ID: DOC-0002653
Project: PRJ-040
Uploaded on: 2026-04-15
Uploaded by: user136
Export class: EAR99

Assembly of P-102443 at plant PLT04

Part Number: P-102443
Revision: A.1
Plant: PLT04
Station: ST-24
Torque (Nm): 2.5
Cycle time (s): 36

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Clean mating surface

Step 8: Apply thread locker

Assembly of P-102428 at plant PLT03

Part Number: P-102428
Revision: A.1
Plant: PLT03
Station: ST-34
Torque (Nm): 12
Cycle time (s): 60

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Move to next station

Step 4: Move to next station

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Torque to specification

Step 8: Torque to specification

Assembly of P-100002 at plant PLT03

Part Number: P-100002
Revision: C.1
Plant: PLT03

Station: ST-11
Torque (Nm): 12
Cycle time (s): 34

Step 1: Fit fasteners

Step 2: Record result

Step 3: Record result

Step 4: Record result

Step 5: Record result