EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002658
Project: PRJ-037
Uploaded on: 2026-04-17
Uploaded by: user020
Export class: ECCN-3A001

Assembly of P-100969 at plant PLT04

Part Number: P-100969
Revision: B.1
Plant: PLT04
Station: ST-25
Torque (Nm): 8
Cycle time (s): 171

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Visual check

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Move to next station

Assembly of P-102065 at plant PLT03

Part Number: P-102065
Revision: A.1
Plant: PLT03
Station: ST-72
Torque (Nm): 2.5
Cycle time (s): 243

Step 1: Clean mating surface

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Move to next station

Step 6: Fit fasteners

Step 7: Inspect incoming part

Step 8: Move to next station

Assembly of P-103977 at plant PLT02

Part Number: P-103977
Revision: A.1
Plant: PLT02

Station:	ST-65
Torque (Nm):	2.5
Cycle time (s):	88

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Inspect incoming part