WORK INSTRUCTION

Document ID: DOC-0002672
Project: PRJ-003
Uploaded on: 2026-04-23
Uploaded by: user019
Export class: EAR99

Assembly of P-103461 at plant PLT02

Part Number: P-103461
Revision: A.1
Plant: PLT02
Station: ST-19
Torque (Nm): 2.5
Cycle time (s): 180

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Visual check

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Clean mating surface

Assembly of P-100509 at plant PLT02

Part Number: P-100509
Revision: B.1
Plant: PLT02
Station: ST-74
Torque (Nm): 2.5
Cycle time (s): 246

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Record result

Step 5: Torque to specification

Assembly of P-103579 at plant PLT03

Part Number: P-103579
Revision: A.1
Plant: PLT03
Station: ST-19
Torque (Nm): 5
Cycle time (s): 140

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Fit fasteners

Step 7: Move to next station