EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002710
Project: PRJ-002
Uploaded on: 2026-05-19
Uploaded by: user109
Export class: ECCN-3A001

Assembly of P-103238 at plant PLT04

Part Number: P-103238
Revision: A.1
Plant: PLT04
Station: ST-81
Torque (Nm): 12
Cycle time (s): 209

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Visual check

Assembly of P-102596 at plant PLT01

Part Number: P-102596
Revision: B.1
Plant: PLT01
Station: ST-85
Torque (Nm): 2.5
Cycle time (s): 247

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Record result

Step 6: Visual check

Step 7: Torque to specification

Step 8: Record result