EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002744
Project: PRJ-023
Uploaded on: 2026-06-03
Uploaded by: user141
Export class: ECCN-3A001

Assembly of P-103590 at plant PLT04

Part Number: P-103590
Revision: A.1
Plant: PLT04
Station: ST-14
Torque (Nm): 20
Cycle time (s): 90

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Move to next station

Step 5: Record result

Step 6: Clean mating surface

Step 7: Clean mating surface

Step 8: Fit fasteners

Assembly of P-103188 at plant PLT03

Part Number: P-103188
Revision: A.1
Plant: PLT03
Station: ST-94
Torque (Nm): 20
Cycle time (s): 32

Step 1: Record result

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Record result

Step 6: Apply thread locker