EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002804
Project: PRJ-035
Uploaded on: 2026-06-30
Uploaded by: user199
Export class: ECCN-3A001

Assembly of P-102316 at plant PLT04

Part Number: P-102316
Revision: A.1
Plant: PLT04
Station: ST-23
Torque (Nm): 5
Cycle time (s): 277

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Fit fasteners

Step 7: Apply thread locker

Step 8: Move to next station

Assembly of P-103684 at plant PLT02

Part Number: P-103684
Revision: A.1
Plant: PLT02
Station: ST-62
Torque (Nm): 2.5
Cycle time (s): 53

Step 1: Record result

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Record result

Assembly of P-101801 at plant PLT03

Part Number: P-101801
Revision: A.1
Plant: PLT03

Station:	ST-31
Torque (Nm):	5
Cycle time (s):	91

Step 1: Visual check

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Fit fasteners

Step 7: Record result

Step 8: Clean mating surface