# WORK INSTRUCTION

**Document ID:** DOC-0002819
**Project:** PRJ-034
**Uploaded on:** 2026-07-08
**Uploaded by:** user016
**Export class:** EAR99

## Assembly of P-103765 at plant PLT03

**Part Number:** P-103765
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-42
**Torque (Nm):** 2.5
**Cycle time (s):** 173

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Record result

Step 5: Fit fasteners

Step 6: Record result

## Assembly of P-104321 at plant PLT04

**Part Number:** P-104321
**Revision:** A.1
**Plant:** PLT04
**Station:** ST-15
**Torque (Nm):** 20
**Cycle time (s):** 245

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Torque to specification

## Assembly of P-102150 at plant PLT04

**Part Number:** P-102150
**Revision:** C.1
**Plant:** PLT04
**Station:** ST-98
**Torque (Nm):** 12
**Cycle time (s):** 256

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Move to next station

Step 7: Clean mating surface