EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002913
Project: PRJ-032
Uploaded on: 2026-08-17
Uploaded by: user148
Export class: ECCN-3A001

Assembly of P-102161 at plant PLT04

Part Number: P-102161
Revision: A.1
Plant: PLT04
Station: ST-97
Torque (Nm): 5
Cycle time (s): 207

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Visual check

Step 7: Apply thread locker

Assembly of P-101661 at plant PLT03

Part Number: P-101661
Revision: A.1
Plant: PLT03
Station: ST-92
Torque (Nm): 20
Cycle time (s): 151

Step 1: Apply thread locker

Step 2: Record result

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Fit fasteners