EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002970
Project: PRJ-001
Uploaded on: 2026-09-22
Uploaded by: user154
Export class: ECCN-3A001

Assembly of P-100449 at plant PLT02

Part Number: P-100449
Revision: B.1
Plant: PLT02
Station: ST-37
Torque (Nm): 8
Cycle time (s): 151

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Torque to specification

Step 7: Torque to specification

Assembly of P-102191 at plant PLT03

Part Number: P-102191
Revision: A.1
Plant: PLT03
Station: ST-38
Torque (Nm): 20
Cycle time (s): 252

Step 1: Record result

Step 2: Record result

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-102309 at plant PLT04

Part Number: P-102309
Revision: A.1

Plant:	PLT04
Station:	ST-10
Torque (Nm):	5
Cycle time (s):	59

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Clean mating surface

Step 8: Move to next station