WORK INSTRUCTION

Document ID: DOC-0002974
Project: PRJ-031
Uploaded on: 2026-09-23
Uploaded by: user110
Export class: EAR99

Assembly of P-102722 at plant PLT03

Part Number: P-102722
Revision: A.1
Plant: PLT03
Station: ST-45
Torque (Nm): 5
Cycle time (s): 171

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Record result

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Fit fasteners

Assembly of P-103394 at plant PLT02

Part Number: P-103394
Revision: A.1
Plant: PLT02
Station: ST-16
Torque (Nm): 12
Cycle time (s): 87

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Inspect incoming part