WORK INSTRUCTION

Document ID: DOC-0002991
Project: PRJ-017
Uploaded on: 2026-10-03
Uploaded by: user070
Export class: EAR99

Assembly of P-101032 at plant PLT02

Part Number: P-101032
Revision: A.1
Plant: PLT02
Station: ST-61
Torque (Nm): 5
Cycle time (s): 91

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Torque to specification

Assembly of P-104044 at plant PLT02

Part Number: P-104044
Revision: A.1
Plant: PLT02
Station: ST-85
Torque (Nm): 5
Cycle time (s): 104

Step 1: Fit fasteners

Step 2: Record result

Step 3: Torque to specification

Step 4: Record result

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Torque to specification

Assembly of P-101459 at plant PLT03

Part Number: P-101459
Revision: A.1
Plant: PLT03
Station: ST-57
Torque (Nm): 2.5
Cycle time (s): 221

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Record result