WORK INSTRUCTION

Document ID: DOC-0003001
Project: PRJ-012
Uploaded on: 2026-10-06
Uploaded by: user093
Export class: EAR99

Assembly of P-103567 at plant PLT03

Part Number: P-103567
Revision: A.1
Plant: PLT03
Station: ST-68
Torque (Nm): 20
Cycle time (s): 119

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Torque to specification

Step 6: Inspect incoming part

Assembly of P-102330 at plant PLT01

Part Number: P-102330
Revision: A.1
Plant: PLT01
Station: ST-55
Torque (Nm): 12
Cycle time (s): 275

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Move to next station

Assembly of P-102034 at plant PLT01

Part Number: P-102034
Revision: A.1
Plant: PLT01
Station: ST-45
Torque (Nm): 20
Cycle time (s): 215

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Record result

Step 8: Visual check