WORK INSTRUCTION

Document ID: DOC-0003032
Project: PRJ-006
Uploaded on: 2026-10-23
Uploaded by: user118
Export class: EAR99

Assembly of P-104810 at plant PLT02

Part Number: P-104810
Revision: A.1
Plant: PLT02
Station: ST-82
Torque (Nm): 20
Cycle time (s): 260

Step 1: Record result

Step 2: Apply thread locker

Step 3: Record result

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Record result

Step 7: Visual check

Assembly of P-101654 at plant PLT01

Part Number: P-101654
Revision: A.1
Plant: PLT01
Station: ST-78
Torque (Nm): 20
Cycle time (s): 297

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Record result

Assembly of P-101535 at plant PLT03

Part Number: P-101535
Revision: B.1
Plant: PLT03
Station: ST-11
Torque (Nm): 8
Cycle time (s): 293

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Visual check

Step 5: Record result