WORK INSTRUCTION

Document ID: DOC-0000479
Project: PRJ-029
Uploaded on: 2023-06-17
Uploaded by: user192
Export class: EAR99

Assembly of P-100752 at plant PLT01

Part Number: P-100752
Revision: A.1
Plant: PLT01
Station: ST-75
Torque (Nm): 2.5
Cycle time (s): 246

Step 1: Visual check

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Visual check

Step 6: Clean mating surface

Assembly of P-100219 at plant PLT02

Part Number: P-100219
Revision: A.1
Plant: PLT02
Station: ST-48
Torque (Nm): 20
Cycle time (s): 218

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Record result

Step 6: Torque to specification

Assembly of P-100178 at plant PLT03

Part Number: P-100178
Revision: A.1
Plant: PLT03
Station: ST-76
Torque (Nm): 12
Cycle time (s): 102

Step 1: Record result

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Visual check