EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001211
Project: PRJ-038
Uploaded on: 2024-06-16
Uploaded by: user085
Export class: ECCN-3A001

Assembly of P-101297 at plant PLT01

Part Number: P-101297
Revision: A.1
Plant: PLT01
Station: ST-21
Torque (Nm): 5
Cycle time (s): 125

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Visual check

Step 7: Apply thread locker

Step 8: Apply thread locker

Assembly of P-100036 at plant PLT02

Part Number: P-100036
Revision: A.1
Plant: PLT02
Station: ST-90
Torque (Nm): 12
Cycle time (s): 283

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Torque to specification

Assembly of P-101644 at plant PLT01

Part Number: P-101644
Revision: A.1
Plant: PLT01

Station:	ST-79
Torque (Nm):	8
Cycle time (s):	287

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Inspect incoming part