EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002835
Project: PRJ-032
Uploaded on: 2026-07-15
Uploaded by: user031
Export class: ECCN-3A001

Assembly of P-102011 at plant PLT02

Part Number: P-102011
Revision: A.1
Plant: PLT02
Station: ST-30
Torque (Nm): 5
Cycle time (s): 187

Step 1: Record result

Step 2: Visual check

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Record result

Assembly of P-104433 at plant PLT01

Part Number: P-104433
Revision: A.1
Plant: PLT01
Station: ST-82
Torque (Nm): 20
Cycle time (s): 34

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Inspect incoming part

Step 6: Torque to specification

Step 7: Visual check

Assembly of P-103298 at plant PLT03

Part Number: P-103298
Revision: B.1
Plant: PLT03

Station: ST-52
Torque (Nm): 12
Cycle time (s): 222

Step 1: Torque to specification

Step 2: Record result

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Fit fasteners