WORK INSTRUCTION

Document ID: DOC-0001488
Project: PRJ-015
Uploaded on: 2024-10-16
Uploaded by: user111
Export class: EAR99

Assembly of P-102164 at plant PLT04

Part Number: P-102164
Revision: A.1
Plant: PLT04
Station: ST-28
Torque (Nm): 5
Cycle time (s): 264

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Record result

Step 4: Torque to specification

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-100469 at plant PLT03

Part Number: P-100469
Revision: A.1
Plant: PLT03
Station: ST-42
Torque (Nm): 12
Cycle time (s): 258

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Record result

Step 7: Visual check

Assembly of P-100844 at plant PLT03

Part Number: P-100844
Revision: A.1
Plant: PLT03
Station: ST-39
Torque (Nm): 5

Cycle time (s): 273

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Record result