WORK INSTRUCTION

Document ID: DOC-0001129
Project: PRJ-039
Uploaded on: 2024-05-13
Uploaded by: user032
Export class: EAR99

Assembly of P-100218 at plant PLT04

Part Number: P-100218
Revision: B.1
Plant: PLT04
Station: ST-87
Torque (Nm): 12
Cycle time (s): 51

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Torque to specification

Step 8: Record result

Assembly of P-101819 at plant PLT02

Part Number: P-101819
Revision: A.1
Plant: PLT02
Station: ST-30
Torque (Nm): 8
Cycle time (s): 173

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Visual check

Step 5: Visual check

Step 6: Record result

Assembly of P-101020 at plant PLT03

Part Number: P-101020
Revision: A.1
Plant: PLT03
Station: ST-45
Torque (Nm): 8

Cycle time (s): 242

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Move to next station