WORK INSTRUCTION

Document ID: DOC-0001153
Project: PRJ-021
Uploaded on: 2024-05-25
Uploaded by: user060
Export class: EAR99

Assembly of P-101270 at plant PLT03

Part Number: P-101270
Revision: A.1
Plant: PLT03
Station: ST-31
Torque (Nm): 5
Cycle time (s): 162

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Record result

Step 6: Inspect incoming part

Assembly of P-101735 at plant PLT04

Part Number: P-101735
Revision: A.1
Plant: PLT04
Station: ST-72
Torque (Nm): 20
Cycle time (s): 266

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Apply thread locker

Step 7: Clean mating surface

Step 8: Apply thread locker

Assembly of P-101938 at plant PLT03

Part Number: P-101938
Revision: A.1
Plant: PLT03
Station: ST-21
Torque (Nm): 12

Cycle time (s): 266

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Record result

Step 4: Record result

Step 5: Inspect incoming part

Step 6: Visual check

Step 7: Move to next station

Step 8: Inspect incoming part