WORK INSTRUCTION

Document ID: DOC-0001162
Project: PRJ-031
Uploaded on: 2024-05-27
Uploaded by: user175
Export class: EAR99

Assembly of P-101201 at plant PLT04

Part Number: P-101201
Revision: A.1
Plant: PLT04
Station: ST-54
Torque (Nm): 5
Cycle time (s): 200

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Record result

Step 5: Torque to specification

Assembly of P-101840 at plant PLT02

Part Number: P-101840
Revision: A.1
Plant: PLT02
Station: ST-66
Torque (Nm): 2.5
Cycle time (s): 56

Step 1: Record result

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Inspect incoming part

Step 6: Move to next station

Step 7: Fit fasteners

Assembly of P-100704 at plant PLT02

Part Number: P-100704
Revision: A.1
Plant: PLT02
Station: ST-13
Torque (Nm): 12
Cycle time (s): 119

Step 1: Record result

Step 2: Move to next station

Step 3: Record result

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Record result

Step 7: Clean mating surface

Step 8: Move to next station