EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001341
Project: PRJ-022
Uploaded on: 2024-08-11
Uploaded by: user071
Export class: ECCN-3A001

Assembly of P-100969 at plant PLT04

Part Number: P-100969
Revision: A.1
Plant: PLT04
Station: ST-17
Torque (Nm): 20
Cycle time (s): 35

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Visual check

Step 7: Fit fasteners

Step 8: Inspect incoming part

Assembly of P-102009 at plant PLT01

Part Number: P-102009
Revision: A.1
Plant: PLT01
Station: ST-15
Torque (Nm): 2.5
Cycle time (s): 298

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Record result