WORK INSTRUCTION

Document ID: DOC-0002499
Project: PRJ-030
Uploaded on: 2026-02-04
Uploaded by: user198
Export class: EAR99

Assembly of P-100882 at plant PLT03

Part Number: P-100882
Revision: A.1
Plant: PLT03
Station: ST-48
Torque (Nm): 8
Cycle time (s): 203

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Record result

Step 7: Move to next station

Assembly of P-100680 at plant PLT02

Part Number: P-100680
Revision: A.1
Plant: PLT02
Station: ST-52
Torque (Nm): 2.5
Cycle time (s): 246

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Apply thread locker

Assembly of P-102983 at plant PLT03

Part Number: P-102983
Revision: A.1
Plant: PLT03
Station: ST-76
Torque (Nm): 5
Cycle time (s): 68

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Record result

Step 4: Visual check

Step 5: Visual check